

INSTRUCTIONS & TEMPLATE

VS-S6

Ensure to Use Proper Care and Safety Devices!

Required Tools

Level - Drill Bit - 7/16" - Tape - Any Type - Jig Saw

Installing the VS-S6 Fan Unit - Ensure to use all safety precautions

- 1) Cut out the 2 pieces of the template along the solid rectangle line and tape together as detailed below.
- 2) Cut out the center shaded area bordered by the dotted line for ventilation – opening should be $2 \frac{3}{8}'' \times 15 \frac{5}{8}''$
- 3) Ensure the template is level and tape it to the mounting surface in your pre-determined location.
- 4) Mark the cut out area and remove the template.
- 4) Drill a $\frac{7}{16}''$ hole in each corner of the marked area. These holes are starting points for cutting with an appropriate saw.
- 5) Cut out the marked area and install the fan unit as detailed in the installation instructions.

